



Compressor Head 2 and 3

* no illustrated

Item	Description	NO.
2*	Compressor Head stage 2 and 3	7.60.00
3*	Compressor Head stage 2 and 3 complete	7.70.00
5	compressor head stage 2 and 3 with stud bolts items 13 u. 14	7.70.01
7	seal ring	7.10.02
8	stop bolt	7.10.03
9	screw adapter	1.10.06
10	gasket ring A 30 X 36 (copper)	1.10.07
11	screw plug M 22 X 1,5	7.10.10
12	gasket ring A 22 X 27 (copper)	7.10.11
13	stud bolt M 12 X 32	1.10.14
14	stud bolt M 12 X 40	7.10.12
15	Ball Disk Valve complete	4.20.00
16	screw adapter	7.10.13
17	gasket ring A 10 X 14 (copper)	3.11.03
20*	Zinc Protection complete	7.11.00
21	zinc plate	7.11.01
22	cylindrical screw M8 x 30	7.11.02
23	gasket ring a 8 X 14 (copper)	5.11.03
24	cap nut M 8	5.11.04
25*	Suction Valve Grouping stage 3 complete	7.12.00
26	screw adapter	7.12.01
27	gasket ring A 36 X 44 (copper)	7.12.02
28	valve adapter	7.12.03
29	screw plug M 36 X 1,5mm	7.12.06
(15)	Ball Disk Valve complete	4.20.00
31*	Valve ring complete	7.13.00
32	valve ring	7.13.01
33	gasket ring	7.13.02
34	gasket ring	7.13.03
35	Ball Disk Valve complete	5.17.00
36*	Compressor Cover stage 3 complete	7.15.00
37	compressor cover stage 3	7.15.01
38	rubber seal o-ring	5.12.06
39	screw adapter	7.15.03
40	gasket ring	7.15.04
41	hexagon nut M 12	1.10.05
42	hexagon nut M 12	7.10.07
43	check valve for starting air	see 14.10.40
44	cooling water pipe from compressor housing stage 2	see 12.91.60
45	cooling water pipe to intermediate cooler stage 3	see 12.91.15
46	compressed air pipe to intermediate cooler stage 3	see 12.92.11
47	compressed air pipe from intermediate cooler stage 2	see 12.92.10
48	gasket ring A 26 X 32 (copper)	12.92.31

