



Compressor Housing stage 2 and 3 * no illustratedt

| Item | Description | NO. |
|------|--|--------------|
| 1* | Compressor Housing stage 2 and 3 with components | 6.00.00 |
| 3* | Compressor Housing stage 2 and 3 complete with zinc protection | 6.10.00 |
| 4 | compressor housing stage 2 and 3 with stud bolts | 6.10.01 |
| 5 | stud bolt M 12 X 26 | 1.10.04 |
| 6 | stud bolt M 12 X 30 | 4.10.10 |
| 7 | stud bolt M 12 X 32 | 1.10.14 |
| 8 | stud bolt M 12 X 60 | 6.10.15 |
| 9 | cover plate | 3.10.12 |
| 10 | gasket | 3.10.13 |
| 11 | hexagon nut M 12 | 1.10.05 |
| 12 | screw adapter | 1.10.06 |
| 13 | gasket ring A 30 X 36 (copper) | 1.10.07 |
| 14 | screw plug M 18 X 1,5 | 11.75.11 |
| 14a* | gasket ring 18 X 22 (copper) | 14.25.02 |
| 15 | Zinc Protection complete | 1.11.00 |
| 16* | Compressor Liner stage 2 complete | 6.12.00 |
| 18 | compressorliner stage 2 | 6.12.01 |
| 20 | Ball Disk Valve complete | 4.20.00 |
| 21 | rubber seal o-ring | 6.12.02 |
| 22 | gasket ring | 6.12.03 |
| 23* | Lubricating Oil Connection Piece complete | 6.13.00 |
| 24 | lubricating oil connection piece | 6.13.01 |
| 25 | hexagon nut M 20 | 1.16.02 |
| 26 | ring disk 21 X 35 X 3 | 1.16.03 |
| 27 | rubber seal o-ring | 1.16.04 |
| 28 | gasket ring A 12 X 18 | 1.16.06 |
| 29 | vent screw | 12.91.40 |
| 30 | gasket ring A 10 X 16 X 1,5 (Fiber) | 12.91.41 |
| 31 | housing gasket | 3.10.02 |
| 32 | hexagon screw M 12 x 40 | 3.10.05 |
| 33 | hexagon screw M 12 X 45 | 3.10.19 |
| (11) | hexagon nut M 12 | 1.10.05 |
| 34 | lubricating oil pipe fittings | see 13.00.00 |
| 35 | cooling water pipe to cooler stage 1 | see 12.91.59 |
| 36 | cooling water pipe from stage 3 to stage 2 | see 12.91.60 |
| | | |

